



Installation Guide

DEVIreg™ 132

Electronic Thermostat

www.DEVI.com

DEVI® 
by Danfoss

Table of Contents

1	Introduction	3
	1.1 Technical Specifications	4
	1.2 Safety Instructions	5
2	Mounting Instructions	6
3	Settings	10
4	Warranty	12
5	Disposal Instruction	14


1 Introduction

DEVIreg™ 132 is an electronic thermostat to be installed directly on the wall. It is provided with a room sensor to control the room temperature and an additional floor sensor to limit the maximum floor temperature.

The thermostat has a button for adjusting the temperature, with a scale from (⌚) 5-45 °C, and an LED indicator showing standby (green light) and heating periods (red light).

**More information on this product can also be found at:
devireg.devi.com**

1.1 Technical Specifications

Operation voltage	220-240 V~, 50 Hz
Standby power consumption	Max 5W
Relay: Resistive load Inductive load	Max 16 A / 3680 W @ 230 V cos φ= 0.3 max 1 A
Sensing units	NTC 15 kOhm at 25 °C
Sensing values: 0 °C 25 °C 50 °C	42 kOhm 15 kOhm 6 kOhm
Hysteresis	± 0,2 °C
Ambient temperature	0 to +30 °C
Frost protection temperature	5 °C - ❄
Temperature range	5-35 °C room temperature 20-50 °C floor temperature limiter - default 35 °C
Cable specification max	1 x 4 mm ² or 2 x 2,5 mm ²
Ball pressure temperature	75 °C
Pollution degree	Degree 2 (domestic use)
Type	1C
Storage temperature	-20 to +65 °C
IP class	30
Protection class	Class II - 

Dimensions	82 x 82 x 36 mm
Weight	90 g

The product complies with the EN/IEC Standard “Automatic electrical controls for household and similar use”:

- EN/IEC 60730-1 (general)
- EN/IEC 60730-2-9 (thermostat)

1.2 Safety Instructions

Make sure the mains supply to the thermostat is turned off before installation.

IMPORTANT: When the thermostat is used to control a floor heating element in connection with a wooden floor or similar material, always use a floor sensor and never set the maximum floor temperature to more than 35°C.

Please also note the following:

- The installation of the thermostat must be done by an authorized and qualified installer according to local regulations.
- The thermostat must be connected to a power supply via an all-pole disconnection switch.
- The sensor is to be considered as live voltage. Have this in mind if the sensor must be extended.

- Always connect the thermostat to continuous power supply.
- Do not expose the thermostat to moisture, water, dust, and excessive heat.

2 Mounting Instructions

Please observe the following placement guidelines:



Place the thermostat at a suitable height on the wall (typically 80-170 cm.).



In wet rooms, place the thermostat according to local regulation on IP classes.



Do not place the thermostat on the inner side of an exterior wall.



Always install the thermostat at least 50 cm from windows and doors.



Do not place the thermostat in a way that it will be exposed to direct sunlight.




Note: A floor sensor enables a more accurate temperature control and is recommended in all floor heating applications and **mandatory** under wooden floors to reduce the risk of over-heating the floor.

- Place the floor sensor in a conduit in an appropriate place where it is not exposed to sunlight or draft from door openings.
- Equally distant and >2cm from two heating cables.
- The conduit should be flush with the floor surface - countersink the conduit if necessary.
- Route the conduit to the connection box.
- The bending radius of the conduit must be min 50mm.


Follow the steps below to mount the thermostat:

1. Open the thermostat:




- Remove the button to get access to the screw which holds the front.
- Loosen the screw.
- Push down the release tab at the top of the thermostat using a flat object while slowly pulling off the front cover.

- Fasten the thermostat directly to the wall by driving the screws through the holes in each side of the thermostat.



1 = Screw holes for fastening the thermostat.

- Connect the thermostat according to the connection diagram.



The screen of the heating cable must be connected via a connector together with the earth conductor of the power supply cable.


Note: Always install the floor sensor in a conduit in the floor.

4. Set the maximum floor temperature between 20 °C and 50 °C by using a thin screwdriver on the black electronic component with temperature indications in the upper right corner.
5. Install the front cover and button in the reverse order of disassembly.
6. Turn on the power supply.

3 Settings

How to change the minimum and maximum floor temperatures

1. Lift off the adjustment button using a thin screwdriver. **①**
2. Move the pins to the desired positions. (**②** and **③**)
3. Put the adjustment button back in place.



Please be aware of the following:

- The floor temperature is measured where the sensor is placed.
- The temperature of the bottom of a wooden floor can be up to 10 degrees higher than the top.

- Floor manufactures often specify the max temperature on the top surface of the floor (usually 27-28 °C).
- By default, the maximum floor temperature is set to 35 °C.
- Always use a floor sensor or a room + floor sensor combination to control floor heating. Without a floor sensor, the temperature control may be less accurate and you risk overheating the floor.

Thermal resistance [m²K/W]	Examples of flooring	Details	Approximate setting for 25 °C floor temperature
0,05	8 mm HDF based laminate	> 800 kg/m ³	28 °C
0,10	14 mm beech parquet	650 - 800 kg/m ³	31 °C
0,13	22 mm solid oak plank	> 800 kg/m ³	32 °C
< 0,17	Max. carpet thickness suitable for floor heating	acc. to EN 1307	34 °C
0,18	22 mm solid fir planks	450 - 650 kg/m ³	35 °C

4 Warranty

A 2-year product warranty is valid for:

- thermostats: DEVReg™ 132.

Should you, against all expectations, experience a problem with your DEVI product, you will find that Danfoss offers DEVReg warranty valid from the **date of purchase** on the following conditions: During the warranty period Danfoss shall offer a new comparable product or repair the product if the product is found to be faulty by reason of defective design, materials or workmanship. The repair or replacement.

The decision to either repair or replace will be solely at the discretion of Danfoss. Danfoss shall not be liable for any consequential or incidental damages including, but not limited to, damages to property or extra utility expenses. No extension of the warranty period following repairs undertaken is granted.

The warranty shall be valid only if the WARRANTY CERTIFICATE is completed correctly and in accordance with the instructions, the fault is submitted to the installer or the seller without undue delay and proof of purchase is provided. Please note that the WARRANTY CERTIFICATE must be filled in, stamped and signed by the authorized installer performing the installation (Installation date must be indicated). After the installation is performed, store and keep the WARRANTY CERTIFICATE and purchase documents (invoice, receipt or similar) during the whole warranty period.

DEVReg warranty shall not cover any damage caused by incorrect conditions of use, incorrect installation or if installation has been carried out by non-authorized electricians. All work will be invoiced in full if Danfoss is required to inspect or repair faults that have arisen as a result of any of the above. The DEVReg warranty shall not extend to products which have not been paid in full. Danfoss will, at all times, provide a rapid and effective response to all complaints and inquiries from our customers.

The warranty explicitly excludes all claims exceeding the above conditions.

For full warranty text visit **www.devi.com**.
devi.danfoss.com/en/warranty/

WARRANTY CERTIFICATE

The DEVI warranty is granted to:

Address _____ Stamp _____

Purchase date _____

Serial number of the product _____

Product _____ Art. No. _____

*Connected output [W] _____

Installation Date & Signature _____ Connection Date & Signature _____

**Not mandatory*



5 Disposal Instruction



Danfoss A/S

Nordborgvej 81
6430 Nordborg, Syddanmark
Denmark

Danfoss A/S

DEVI • devl.com • +45 7488 2222 • EH@danfoss.com

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues, descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material. Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.

All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.

DEVreg™ 132

140F1011

220-240V~

50-60Hz~


+5 to +35°C

Temp. Limit +20 to

+50°C

16A/3680W@230V~

IP 30



Product documentation

DK EL 7224215014

SE EL XXXXXX

NO EL 5402692

FI SSTL 3531132



For UK customer only: Importer:
Danfoss Ltd., 22 Wycombe End, HP9 1NB, GB

Designed in Denmark for Danfoss A/S

