

Съвместимо с модели на телевизори БЕКО и Crown

14272TDS
142746TS
14B7M02TXS
14B9M03TXS
14B9M04S
14B9T46TXS
14B9T56SILVERTX
14B9T56TX
14B9T56TXSILVER
14B9T61
14B9T61TXS
14C1T46T
14C1T56TXSILVER
14C2M02TX
14C2M03TXSILVER
14E1T46TS
14E1T46TS D4T000
14E1T56TXSILVER
14E1T56TXSILVER D1B000
14K38SILVER
14K39TX
14K39TXN
14K39TXS
14M01R
14M01TXG
14M03XS
14M03XSH
14M03XSHM
14M04S
14M04TXS
14M15
14M32TX
14M41SILVER
14T46
14T46BLACK
14T46G
14T46M
14T46R

14T46S
14T46TX
14T46TXS
14T56TXS
14T61
14T610
14T61BLACK
14T71XS
15E169TS
15K69TXS
20272TDS
20B9T01TXS
20B9T36TXS
20B9T57TXS
20B9T58TXS
20B9T58TXSILVER
20B9T59
20B9T59S
20B9T59TXS
20C1M06T
20C1T57T
20C2M07TX
20E107TS
20E1M06TS
20E1T58TXSILVER
20K07TX
20K07TXS
20M05SIAV
20M06SILVERNONTEXT
20M07TXS
20M07XS
20M14
20T01
20T01AVXS
20T01TXSIL
20T570T
20T57BLACK
20T57TX
20T57TXS
20T58TX
20T58TXS
20T58TXSIL

20T59S
21B9M10XS
21B9M12XS
21B9T02S
21B9T02TXS
21B9T02XS
21B9T29S
21B9T29TXS
21B9T34SILVERTX
21B9T34TXS
21B9T34XS
21B9T37S
21B9T44TXS
21B9T44XS
21B9T45SILVERTX
21B9T60
21B9T60TXS
21B9TG1TXS
21B9TG1XS
21C1T31MXS
21C1T31TXS
21C1T44T
21C2M10T
21C2M12TX
21E1M11TX
21E1T04TXS
21E1T44S
21E1T95TX
21K13BLACKTX
21K13SILVER
21M10S
21M10XS
21M11TX
21M11TXS
21M11TXSIL
21M12TXS
21PFE1T31XS
21PFT830T
21T02S
21T04
21T04SILTX
21T29

21T29SILVER
21T29TXSIL
21T31PFSILVER
21T31PFTX
21T31PFTXSIL
21T31TXS
21T32TXS
21T34AVXS
21T34TXG
21T34TXSIL
21T440T
21T44BLACK
21T44SILVER
21T44TX
21T44TXM
21T44TXS
21T45SILTX
21T45SILVER
21T45SILVER
21T45TX
21T45TXS
21T45TXSIL
21T60
21T600T
21T60G
21T60SILTX
21T60SILVER
21T60TX
21T60TXS
21T93TX
21T94TX
21T94TXS
21T95SILVER
21T96SILVER
21TG1TXS
36BE970
36M15S
36M15S
5007S
55T02S
B21M12
BCT351COV

BCT51COV
BK14T
BK207
BK20M
BKF21T
CTV14M15SILVER
CTV14M15TLXSILVER
CTV14T612SP
CTV20T57TLXSILVER
CTV21T44TLXSILVER
KK14M03S
KK14M03TXS
KK14T46TXS
KK14T61TXS
KK20M07SXS
KK20T01TXS
KK20T57TXS
KK20T59TXS
KK21M11TXS
KK21T34TXS
KK21T44TXS
KK21T60TXS
M17SIAV
M837X
M837X
PLTVB1011S
PM0314BS
PM0314XBS
PM1121XBS
PM1121XBS
PM1121XBS ER8000
PM1121XBS M56000
TM21T
TR215
TV14K39SILVER
TVB10011S
TVB10015S
TVB1135S
TVB20015S
TVB3015S
TVB7011S
TVB7017 NC6000

TVB7017S
TVB7017S NC5000
TVB8011S
TVB8017S
TVB9916S
TVBC14S
TVBC20S
TVC14E1K38TX
TXTV051SI

3a CROWN

ACTV20C05TXPR
ACTV20C05TXPRAT
ACTV20C01TXPR
ACTV3724DPRAT
ACTV5124PR
CTV14C01TXPRATEADO
CTV20C01TXPRATEADO
CTV37144
CTV3714NP
CTV3714NPTXPRAT
CTV3715
CTV3723PRAT
CTV3724DTXPRAT
CTV3724PRAT
CTV3725TXPRAT
CTV3726DPRAT
CTV3726TXPRAT
CTV5123PRAT
CTV5124PRAT
CTV5125PRAT
CTV5126PRAT
CTV5524PRAT
CTV80514TX
CTV80515TX
CTV8051TX